





















Ref #	Part Number	Qty	Description
1	772063A		Cover Assembly (Incl. 2 & 73)
2	780013		Needle Bearing
2A	780088		Needle Bearing
3	770052		Case Assembly (Incl. 2 & 2A)
5	778041		Output Pinion
6	778036		Output Gear
13	778104		Bevel Gear (4 teeth-steel)
14	778014		Bevel Pinion (14 teeth-steel)
15	778033A		Ring Gear
16	786027		Drive Block
17	786019		Drive Pin
18	786017		Spacer
24	780039	1300-1317 Peerless #1	Thrust Bearing (NOTE: One (1) washer 780107 can be used interchangeably in place of two (2) 780042 washers and one (1) 780039 thrust bearing in this location only.)
25	792046		Screw, 1/4-20 x 1"
26	792018		Snap Ring
29	780001		Washer
31	780042		Thrust Washer
31B	780042		Thrust Washer (NOTE: One (1) washer 780107 can be used interchangeably in place of two (2) 780042 washers and one (1) 780039 thrust bearing in this location only.)
31A	780107		Washer
39	786026		Dowel Pin
67	776093		Brake Shaft
73	780089		Needle Bearing
76	780090		Washer
79	792144		Brake Spring
85	792010		Pipe Plug
87	788008		Oil Seal
101	774028A		Differential Carrier
102	774029A		Differential Carrier
103	792020		Screw, 1/4-20 x 2-1/4"
104	792006		Lockwasher, 1/4"
124	788044A		Case-to-Cover Gasket
124A	788046		Gasket
132	778083		Idler Gear (29 teeth)
136	782022A		L.H. Housing & Bushing (Incl. 137)
137	780054		Bushing
138	782022A		R.H. Housing & Bushing (Incl. 137)
180	730229A		Gear Oil SAE 80W90

47 	VIEW 2 of 2	48 
47A 		48A 
47B 		48B 
47C 		48C 
47D 		48D 
47E 		48E 
47F 		48F 
47G 		48G 
47H 		48H 
47I 		48I 

Ref #	Part Number	Qty	Description
47E	774432		Axle (8-1/2" long)
48E	774432		Axle (8-1/2" long)

1300-1317 Page 4 of 4
Peerless #2