


**ROTARY LAWN MOWER -- MODEL NUMBER AG65N21CH (AG65N21CHA)**



**ROTARY LAWN MOWER - - MODEL NUMBER AG65N21CH (AG65N21CHA)**

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	131696	Control Bar	38	160828	Bolt, Shoulder
2	166860X479	Upper Handle	39	83923	Flanged Locknut
3	161105X479	Lower Handle	41	88652	Hinge Screw
4	179585	Rope Guide	42	165766	Spring, LH
5	73800400	Locknut 1/4-20	43	165767	Spring, RH
6	131959	Handle Bolt	44	185819	Rod
7	66426	Wire Tie	45	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
8	161551	Bolt	46	141846	Danger Decal
9	154132	Hinge Bracket	48	180410X004	Axle Arm Assembly, RR
10	165754	Mulcher Door	52	190325	Kit, Housing (Includes Key Numbers 17, 18 and 46)
11	149293	Engine Zone Control Cable	53	851084	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
12	750634	Hex Washer Head Screw #10-24 x 1/2	54	850263	Helical Lockwasher
13	850733X004	Up-Stop Bracket	55	851074	Hardened Washer
14	136376	Handle Knob	56	189028	21" Blade
15	51793	Hairpin Cotter	57	184590	Blade Adapter
16	147286	Hinge Rod	58	88652	Hinge Screw
17	165946X479	Support Bracket	59	751152	Nut, Hex
18	17600406	Screw	60	83816	Screw
19	186577X004	Axle Arm Assembly, LF	61	111190X	Clamp, Cable
20	186578X004	Axle Arm Assembly, RF	67	190011	Grass Bag
21	188987	Rear Skirt	68	188813	Frame, Grass Bag
22	168360X004	Selector Spring, Front	70	---	Engine, B&S, Model Number 123K02 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
23	186612	Kit, Rear Door Assembly (Includes Springs)	71	700417	Throttle Control
24	73800500	Locknut, Hex 5/16-18	72	183365	Screw
25	186212X479	Handle Bracket Assembly, LH	73	132004	Nut, Hex
26	186213X479	Handle Bracket Assembly, RH	74	166785	Nut, Hex
27	74780512	Screw 1/4-20 x 3/8	75	851856	Screw
28	152124	Hinge Spring	77	73930500	Nut, Hex
29	160835X007	Wheel Adjusting Bracket, Front	78	146247	Wheel Assembly
30	183901	Washer	--	161058	Warning Decal (Not Shown)
31	165760	Deflector, Discharge	--	172782	Operator's Manual, English
32	168360X004	Selector Spring, Rear	--	172784	Operator's Manual, Spanish
33	87877	Selector Knob	--	190021	Repair Parts Manual
34	180409X004	Axle Arm Assembly, LR			
35	73990500	Nut, Hex			
36	164362	Shoulder Bolt 5/16-18			
37	190013	Wheel Assembly			

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm