


ROTARY LAWN MOWER -- MODEL NUMBER RK45N22SHA



ROTARY LAWN MOWER -- MODEL NUMBER RK45N22SHA

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	73800400	Locknut, Hex 1/4-20	47	800220	Wheel Assembly, Front
2	86902	Control Bar	51	74760514	Bolt, Hex Head 5/16-18
3	179585	Rope Guide	52	150406	Screw, Hex Head, Threaded, Rolled 3/8-16 x 1
4	169709X479	Upper Handle	55	107339X	Danger Decal
5	169708X479	Lower Handle	59	165187	Lawn Mower Housing (Includes Key Number 55)
7	131959	Handle Bolt 5/16-18	61	851514	Blade Adapter
11	162778	Engine Zone Control Cable	62	141114	22" Blade
12	750364	Hex Washer Head Screw #10-24 x 1/2	63	851074	Hardened Washer
13	86899X004	Up-Stop Bracket	64	850263	Helical Lockwasher 3/8
16	128638	Wing Nut	65	851084	Screw, Hex Head 3/8-24 x 1-3/8 Grade 8
19	51793	Hairpin Cotter	67	---	Engine, Briggs & Stratton, Model Number 10M902 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
21	188987	Rear Deflector			
22	66426	Wire Tie			
23	160831	Discharge Guard	70	180409X004	Axle Arm Assembly, LR
27	160832	Torsion Spring	72	186577X004	Axle Arm Assembly, LF
30	160833	Hinge Rod	73	186578X004	Axle Arm Assembly, RF
33	73800500	Locknut, Hex 5/16-18	74	166785	Nut, Hex
34	170373X479	Wheel Bracket Support, LH	76	161622	Clip, Closeout
35	170374X479	Wheel Bracket Support, RH	77	74760412	Screw
36	160835X007	Wheel Bracket Adjuster	79	160830	Mulcher Plate
39	168360X004	Selector Spring	85	132004	Nut, Hex
40	87877	Selector Knob	--	162300	Warning Decal (not shown)
41	180410X004	Axle Arm Assembly, RR	--	172782	Operator's Manual, English
43	183901	Washer	--	172783	Operator's Manual, French
44	160828	Shoulder Bolt	--	190322	Repair Parts Manual, English / French
45	188808	Wheel Assembly, Rear			
46	83923	Locknut, Hex 1/16-18			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm