


ROTARY LAWN MOWER -- MODEL NUMBER SO4QN22SHA



ROTARY LAWN MOWER - - MODEL NUMBER SO4QN22SHA

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	63601	Locknut 1/4-20	48	571143	Washer
2	86902	Control Bar	51	74760514	Hex Head Bolt 5/16-18
3	179585	Rope Guide	52	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
4	169709X479	Upper Handle	55	141846	Danger Decal
5	169708X479	Lower Handle	59	185305	Lawn Mower Housing (Includes Key No. 55)
7	131959	Handle Bolt 5/16-18	61	851514	Blade Adapter
11	176556	Engine Zone Control Cable	62	141114	22" Blade
12	750634	Hex Washer Head Screw #10-24 x 1/2	63	851074	Hardened Washer
13	86899X004	Up-Stop Bracket	64	850263	Helical Lockwasher 3/8
16	136376	Wing Nut	65	851084	Screw Hex Head 3/8-24 x 1-3/8 (Grd. 8)
19	51793	Hairpin Cotter	67	- - -	Engine, Briggs & Stratton, Model No. 10A902 (Order parts from engine manufacturer)
21	165858	Rear Deflector	70	180409X004	Axle Arm Assembly (LR)
22	66426	Wire Tie	72	167132X004	Axle Arm Assembly (LF)
23	160831	Discharge Guard	73	167133X004	Axle Arm Assembly (RF)
27	160832	Torsion Spring	74	751153	Nut
30	160833	Hinge Rod	76	161622	Clip, Closeout
33	63124	Locknut 5/16-18	77	74760412	Screw
34	170373X479	Wheel Bracket Support (Left)	79	160830	Mulch Plate
35	170374X479	Wheel Bracket Support (Right)	84	166785	Nut, Flange
36	160835X007	Wheel Bracket Adjuster	85	132004	Nut, Hex
39	168360X004	Selector Spring	- -	161058	Warning Decal (Not Shown)
40	87877	Selector Knob	- -	172782	Operator's Manual (English)
41	180410X004	Axle Arm Assembly (RR)	- -	172784	Operator's Manual (Spanish)
43	183901	Washer	- -	185316	Replacement Parts Manual (English)
44	160828	Shoulder Bolt			
45	185457	Wheel Assembly (Rear)			
46	83923	Locknut 1/16-18			
47	800220	Wheel Assembly (Front)			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm