


ROTARY LAWN MOWER -- MODEL NUMBER W4QN22SC



ROTARY LAWN MOWER - - MODEL NUMBER W4QN22SC

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	132004	Locknut 1/4-20	52	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
2	86902	Control Bar	55	141846	Danger Decal
3	179585	Rope Guide	59	163326	Lawn Mower Housing (Includes Key Number 55)
4	169709X479	Upper Handle	61	851514	Blade Adapter
5	169708X479	Lower Handle	62	141114	22" Blade
7	131959	Handle Bolt 5/16-18	63	851074	Hardened Washer
11	133107	Engine Zone Control Cable	64	850263	Helical Lockwasher 3/8
12	750634	Hex Washer Head Screw #10-24 x 1/2	65	851084	Screw Hex Head 3/8-24 x 1-3/8 (Grade 8)
13	850733X004	Up-Stop Bracket	67	- - -	Engine, Briggs & Stratton, Model Number 10A902 (Order parts from engine manufacturer)
16	136376	Handle Knob	72	167132X004	Axle Arm Assembly (LF / RR)
19	51793	Hairpin Cotter	73	167133X004	Axle Arm Assembly (RF / LR)
21	165858	Rear Deflector	74	166785	Nut
22	66426	Wire Tie	76	161622	Clip. Closeout
23	160831	Discharge Guard	77	750097	Screw
27	160832	Torsion Spring	78	87584X004	Shoulder Bolt 5/16-18X.51
30	160833	Hinge Rod	79	160830	Mulcher Plate
33	73930500	Nut Hex Flange Lock 5/16 - 18	80	164137	Throttle Control
34	168164X479	Wheel Bracket Support (Left)	81	144929	Screw
35	168165X479	Wheel Bracket Support (Right)	82	111190X	Clamp
36	160835X007	Wheel Bracket Adjuster	83	83816	Screw
39	168360X004	Selector Spring	- -	161058	Warning Decal (Not Shown)
40	87877	Selector Knob	- -	172782	Operator's Manual, English
43	183901	Washer	- -	172784	Operator's Manual, Spanish
44	160828	Shoulder Bolt 5/16-18 x .33	- -	185903	Replacement Parts Manual
45	107644X	Wheel Assembly			
46	83923	Locknut 1/16-18			
50	77400	Hubcap			
51	17600406	Screw, Hex Head, Serrated 1/4 x 20.tt			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm