


ROTARY LAWN MOWER - - MODEL NUMBER W4QN22SHB



ROTARY LAWN MOWER - - MODEL NUMBER W4QN22SHB

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	63601	Locknut 1/4-20	52	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
2	86902	Control Bar	55	107339X	Danger Decal
3	179585	Rope Guide	59	163326	Lawn Mower Housing (Incl. Key Nos. 55)
4	169709X479	Upper Handle	61	851514	Blade Adapter
5	169708X479	Lower Handle	62	141114	22" Blade
7	131959	Handle Bolt 5/16-18	63	851074	Hardened Washer
11	851671	Engine Zone Control Cable	64	850263	Helical Lockwasher 3/8
12	750097	Hex Washer Head Screw #10-24 x 1/2	65	851084	Screw Hex Head 3/8-24 x 1-3/8 (Grd. 8)
13	850733X004	Up-Stop Bracket	67	- - -	Engine, Briggs & Stratton, Model No. 10A902 (Order parts from engine manufacturer)
16	136376	Wing Nut	70	180409X004	Axle Arm Assembly (LR)
19	51793	Hairpin Cotter	72	167132X004	Axle Arm Assembly (LF)
21	165858	Rear Deflector	73	167133X004	Axle Arm Assembly (RF)
22	66426	Wire Tie	74	751153	Nut
23	160831	Discharge Guard	76	161622	Clip, Closeout
27	160832	Torsion Spring	77	74760412	Screw
30	160833	Hinge Rod	79	160830	Mulch Plate
33	63124	Locknut 5/16-18	80	700644	Throttle Control
34	170373X479	Wheel Bracket Support (Left)	81	144929	Screw
35	170374X479	Wheel Bracket Support (Right)	82	111190X	Clamp
36	160835X007	Wheel Bracket Adjuster	83	83816	Screw
39	168360X004	Selector Spring	84	61537	Washer
40	87877	Selector Knob	85	132004	Nut, Hex
41	180410X004	Axle Arm Assembly (RR)	--	162300	Warning Decal (Not Shown)
43	19112222	Washer	--	172782	Operator's Manual (English)
44	160828	Shoulder Bolt	--	172783	Operator's Manual (French)
45	180206	Wheel Assembly (Rear)	--	181455	Replacement Parts Manual
46	83923	Locknut 1/16-18			
47	86984	Wheel Assembly (Front)			
48	57143	Washer			
50	77400	Hubcap			
51	74760514	Hex Head Bolt 5/16-18			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm