
For Discount Tecumseh Engine Parts Call 606-678-9623 or 606-561-4983 H60-75450M Page 1 of 5 Engine Parts List



Ref #	Part Number Qty	Description
	34919A	Cylinder (Incl. 2,3 & 4) (2-5/8" Bore)
	27652	Pin, Dowel
	27642	Pipe plug, 1/4-18
	9556	Pipe plug, 1/8-27
	32630	Seal, Oil
	29536	
5	29030	Blower Housing Baffle (Without electric starter knock out)
		(Use as required)
5	35256A	Blower Housing Baffle (With electric starter knockout) (As
		req.)(point ign.)
6	650561	Screw, 1/4-20 x 5/8"
	29538	•
	650542	Base, Engine mounting Screw, 5/16-18 x 3/4"
	34886	Crankshaft
	29783	Pin, Crankshaft gear (Used on early p rod.)
11	27884	Gear, Crankshaft (Used on early production) This gear is
		serviceable ONLY when it is pinned to the crankshaft.
13A	33312B	Piston & Pin Ass'y. (Std.)(2-5/8")(In cl.14)
13A	33313B	Piston & Pin Ass'y. (.010" OS) (Incl. 14)
13A	33314B	Piston & Pin Ass'y. (.020" OS) (Incl. 14)
13	34531	Piston, Pin & Ring Set (Std.) (2-5/8" Bore)
	34532	Piston, Pin & Ring Set (.010" OS)
13	34533	Piston, Pin & Ring Set (.020" OS)
	27888	Ring, Piston pin retaining
	34854	Ring Set (Std.) (2-5/8" Bore)
	34855	Ring Set (.010" OS)
	34856	Ring Set (.020" OS)
	31380C	Rod Assy., Connecting (Incl. 17)
	650662C	Bolt, Connecting rod (Incl. 2 pieces)
	34034	Lifter, Valve
	30622A	Extension, Blower housing
	650128	Screw, 10-24 x 1/2"
	650561	Screw, 1/4-20 x 5/8" (Use as required)
	30063	Screw, $1/4-20 \times 1/2$ " (Use as required)
	30684	Gasket Cylinder Cover
	31451A	Cylinder Cover (Incl.26, 34, 127A, 12 9 & 130)
	28460	Seal, Oil
	650488	Screw, 1/4-20 x 1-1/4"
	650493	Screw, 1/4-20 x 1-3/4"
	30699C	Rod Assy., Governor (Incl. 30 & 31)
	30700	Yoke, Governor
	650494	Screw, 6-40 x 5/16"
	29642	Ring, Retaining
	31845	Shaft, Mechanical governor
	30588A	Spool, Governor
	35479	Washer, Flat
	29193	Ring, Retaining
	30591	Gear Assy., Governor
	31843A	Bracket, Governor gear
	650836	Screw, $10-24 \times 1/2$ "
	32783	Intake Valve (Std.)
	32784	Intake Valve (310.) Intake Valve (1/32" OS)
	27878A	Exhaust Valve (Std.)
	27880A	Exhaust Valve (1/32" OS)
	27882	Cap, Upper valve spring
	27881	Spring, valve
45	32581	Cap, Lower valve spring
	// // // // // // // // // // // /	

Ref #	Part Number	Qty	Description	
46	33876		Gasket, Stator	
47	650516		Screw, 1/4-20 x 1-1/8"	
	32589		Key, Flywheel	
	28938C		Gasket, Cylinder head	
	30938A		Head, Cylinder	
	33636		Resistor Spark Plug (RJ-8C)	
	610118		Cover, Spark plug (Use as required)	
	30939A		Cover Assy., Cylinder head	
56B	650690		Washer, Belleville (Use as required)	
56A	650691		Washer, Flat (Use as required)	
56	650697A		Screw, 5/16-18 x 2-1/2" (Use as required)	
	650694A		Screw, 5/16-18 x 2" (Use as required)	
	650695A		Screw, 5/16-18 x 2-1/4" (Use as required)	
	30322		Locknut, 8-32	
	29916			
			Clamp, Governor lever (Use as require d)	
	33454		Lever Assy., Governor	
	29918		Washer, Lock, No. 8 E.T.	
61	650548		Screw, 8-32 x 5/16"	
62	29216		Locknut, 10-32	
63	29826		Screw, 10-32 x 3/4"	
65	34662		Link, Throttle	
	34661		Link, Governor	
	34664		Control Bracket (Incl. 68, 69, 72 & 1 38)	
	31342		Spring, Compression	
	650549		Screw, 5-40 x 7/16"	
	27793		Clip, Conduit	
71	28942		Screw, 10-32 x 3/8"	
72	610973		Terminal Assy. (Use as required)	
74	27896A		Gasket, Valve chamber cover	
	28423		Breather Assy., Valve	
	28424		Element, Breather	
	28425			
			Cover, Valve spring box	
	650128		Screw, 10-24 x 1/2"	
	35350		Tube Breather	
82	27915A		* Gasket, Intake pipe to cylinder	
83	34712		Flange, Carburetor (Incl. 86A)	
84	30196		Screw, 5/16-18 x 3/4"	
	31688A		* Gasket, Carburetor	
	650517		Screw, 1/4-20 x 13/16"	
	27272A		* Air Cleaner Gasket (Use as required)	
	30767		Spacer, Cleaner (Use as required)	
94A	34819		Elbow Assy., Air cleaner (Incl. 90,91,92,93,94,96) (Use in	
			730561 assembly only)	
101	34158		Bracket, Fuel tank	
	650665		Screw, 1/4-14 x 7/8"	
	34159		Plate, Fuel tank mounting	
104	34186A		Fuel Tank (Incl. 105 & 107) NOTE: These tanks were built	
			with different size fuel inlet openings. Tanks with the 1-3/16"	
			I.D. opening use fuel cap 33032 or 34210. Tanks with the	
			1-1/2" I.D. opening use fuel cap 35355.	
105	33032		Fuel Cap (Red Plastic) (Spurt resistant, Low profile) (Use as	
			required)	
405	24242			
105	34210		Fuel Cap (Red Plastic) (Spurt resistant, High profile) (Use as	
			required)	
105	35355		Fuel Cap (Red plastic) (Use as requir ed)	
105	410144B	***	Fuel Cap (White Plastic)(Std.)(As req uired)	
www.mymowerparts.com				

Ref #	Part Number Qt	y Description
	29774	Fuel Line (Braided, 8 1/4") (Use as r equired)
	30962	Fuel Line (Braided, 32") (Use as required)
	26460	Clamp, Fuel line (Use as required)
	32158E	Blower Housing (For electric starter)
	29747B	Screw, 5/16-24 x 21/32"
	27930A	* Gasket, Exhaust flange
	34390	Deflector, Exhaust (Optional)
	32401	Muffler
	391026	Opt.Spark Arrest Muf.(Incl.143,143A,1 43B)
	33714	Opt.Spark Arrest Muf.(Incl.112,143,14 4,144A)
	30196	Screw, 5/16-18 x 3/4"
	26073	Washer, Flat
	650694A	Screw, 5/16 - 18 x 2"
	32125	Cup, Starter
	35009	Screen, Starter cup
	650815	Washer, Belleville
	8116	Nut, Hex
	29716	Screw, 1/4-28 x 7/16"
	31691	Bracket, Air cleaner
	28820	Screw, 10-32 x 1/2"
	30727	Element, Air cleaner
	31715	Body, Air cleaner
	650152	Screw, 8-32 x 3/8"
	31793	Bearing, Ball
	31855	Retainer, Bearing
	31792	Washer, Thrust
	650778	Washer, Lock
	650580	Nut, Lock
	34663	Spring, Speed control
	650821	Ścrew, 10-32 x 1/2"
	33185	Cover & tube, Muffler (Use as require d)
143A	33171	Screen, Muffler (Use as required)
143	650578	Screw, 8-18 x 3/8" (Use as required)
144A	33323	Screen, Muffler (Use as required)
144	33700	Cover & Tube, Muffler (Use as require d)
145	31297	Dipstick (Incl. 146A)
146A	29673	* Gasket, Oil fill
166	30063	Screw, 1/4-20 x 1/2"
191	34068	Adapter Harness (3 amp)
191	34067	Adapter Harness (3 amp)
193	30985	Control, Throttle
201	730164	Air Cleaner Ass'y. (Red Poly)(Incl.87,120,121,122,123,124 &
		230)(As req.)
201	730164	Air Cleaner Kit, Mini bike (Incl.87,120,121,122,123 & 124)
201	730104	(Use as required) $(110.07, 120, 121, 122, 123, 124)$
201B	730561	Air Cleaner Kit
		(Incl.74,79,80,87,88,89,90,91,92,94,95,96,97,99,100 & 230C)
		(Used only on engine with an externally vented fully
		adjustable carburetor)
201A	730130	Muffler Adapter Kit (Incl.110,112)(As req.)
	34346	Decal, Instruction
	550223	Decal, Name
	30547A	Breaker Assy (Used on Std. Point igni tion)
	610767A	Condenser
	631021	Inlet, Needle Seat & Clip Assy.
	611077	Alternator (Optional)
_ 10		

		Qty	Description
	650868		Screw, 8-18 x 1-1/8" (3 required)(Opt .)
	611078		Connector, A.C. Lighting (Optional)
	611079		Connector, D.C. Charging (Optional)
	590610		Tube, Centering (Optional)
	590613		Alternator Shaft (Optional)
250	632230		Carburetor (Incl. 85) (Refer to Division 5, Section A, Page 182 for breakdown)
251	611040		Magneto NOTE: The complete magneto is not available as an assembly. The magneto number is shown for reference purposes only. Order component parts individually, as shown in parts list. (Refer to Division 5, Section B, page 36 for breakdown)
252	590420A		Rewind Starter (Refer to Division 5, Section C, page 25 for breakdown)
253	33606		Electric Starter Motor (12 volt) (Refer to Division 5, Section D, page 20 for breakdown)
254	33328D		Starter Motor Kit (110-120 volt) This 110-120 volt starter motor kit may have been added to this engine. It can be added only if cylinder hasdrilled and tapped starter mounting bosses and a ring gear flywheel (see#255). Refer to service number stamped on end cap of motor or on decal for identificat
255	30811A		Flywheel (Ring gear flywheel requiredon engines using 110-120 volt starter motor kits listed above) (Used on Std. point ignition before 1982)
255	611042		Flywheel (Ring gear flywheel requiredon engines using 110-120 volt starter motor kits listed above) (Used on Std. point ignition 1982 or later)
255	611085		Flywheel (Minimum ring gear flywheel required on engines using 110-120 volt starter motor kits listed above) (Used on solid state external ignition)
256	33235A		Gasket Set (Incl. items marked*)