ILLUSTRATION SHOWS TYPICAL PARTS ONLY, ORDER BY PART NUMBER, PARTS NOT LISTED ARE SUPPLIED BY DEML



www.mymowerparts.com

Ref # I	Part Number Qt	y Description
	33039	Cylinder (Incl.2,4,30,47,119) (3-5/16 ")
2 2	27652	Pin, Dowel
4 3	31950	Seal, Oil
5 3	31940	Intake Valve (Std.)
5 3	31941	Intake Valve (1/32" OS) (Incl. 9)
6 3	31942	Exhaust Valve (Std.)
	31943	Exhaust Valve (1/32" OS) (Incl. 9)
	650592	Key, Flywheel
	31944	Spring, Valve
	31945	Cap, Lower valve spring (Std.)
	31946	Cap, Lower valve spring (1/32" OS)
	31946	Cap, Lower valve spring (1/32" OS)
	31945	Cap, Lower valve spring (Std.)
	20810	Pin, Valve spring retainer
	33391B	Crankshaft (Incl. 12, 13, 78 & 79)
	29783	Pin, Crankshaft gear
	31931 32001C	Gear, Crankshaft Pioton & Pin Apply (Std.) (Incl. 16)(2, 5/16")
	32001C 32002B	Piston & Pin Ass'y. (Std.)(Incl.16)(3 -5/16")
	32002B 32003B	Piston & Pin Ass'y. (.010" OS) (Incl. 16) Piston & Pin Ass'y. (.020" OS) (Incl. 16)
	32619B	Piston & Pin Ass'y. (.020 '03) (Incl. 16) Piston & Pin Ass'y. (.030" OS) (Incl. 16)
	34508	Piston, Pin & Ring Set (Std.) (3-5/16 " Bore)
	34509	Piston, Pin & Ring Set (0.10" OS)
	34510	Piston, Pin & Ring Set (.020" OS)
	34850	Piston, Pin & Ring Set (.030" OS)
	34523	Piston, Pin & Ring Set (.040" OS)
	32620B	Piston & Pin Ass'y. (.040" OS) (Incl. 16)
	32004	Ring Set (Std.) (3-5/16" Bore)
	32005	Ring Set (.010" OS)
15 3	32006	Ring Set (.020" OS)
15 3	32623	Ring Set (.030" OS)
15 3	32624	Ring Set (.040" OS)
15 3	32321	Re-Ringing Set, Piston
	31919	Ring, Piston pin retaining
	33093A	Connecting Rod Ass'y.(Std.)(Incl.18, 19 & 20)
	34383	Connecting Rod Assy.(.010" US)(Incl.1 8,19,20)
	34384	Connecting Rod Assy.(.020" US)(Incl.1 8,19,20)
	32077	Bolt, Connecting rod
	26073	Washer, Connecting rod
	28264	Nut Assy., Lock
	32150	Camshaft (MCR)
	31939 310564	Lifter, Valve
	31956A	* Gasket, Cylinder cover
	32580A 32908	Cover, Cylinder (Incl. 4, 28, 30, 34, & 43) Oil Fill Tube
	29673	* Gasket, Oil fill tube
25 A 2		"O" Ring
25A 3		"O" Ring
	33055	Dipstick (Incl. 25A)
	32426	Spacer, Governor rod
	650588	Screw, 1/4-20 x 2"
	31968	Link, Governor
	650451	Screw, 1/4-20 x 1"
	31964	Clamp, Governor lever
	29193	Ring, Retaining
	31963	Lever, Governor adjusting
	650518	Lockwasher
	650544	Screw, 10-24 x 7/8"
	WWW MUMOU	iornorta com

Screw, 10-24 x 7/8"

WWW.mymowerparts.com


Ref # Part Number Qty Description 38 7975 Nut, 10-24 39 31965 Plate, Governor spring 40 30312 Screw, 10-32 x 1/2" 41 31967 Spring, Governor 42 30590A Washer, Flat 43 32425 Rod Assy., Governor 44 31948 Spool, Governor 45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650628A Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650603 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as requi red) 53 33636 Resistor Spark Plug (RJ-8C)
39 31965 Plate, Governor spring 40 30312 Screw, 10-32 x 1/2" 41 31967 Spring, Governor 42 30590A Washer, Flat 43 32425 Rod Assy., Governor 44 31948 Spool, Governor 45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650697A Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603
40 30312 Screw, 10-32 x 1/2" 41 31967 Spring, Governor 42 30590A Washer, Flat 43 32425 Rod Assy., Governor 44 31948 Spool, Governor 45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650714 Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650603 Screw, 5/16-18 x 1-3/4" (Use as requi red)
41 31967 42 30590A Washer, Flat Washer, Flat Rod Assy., Governor At 31948 Spool, Governor Ring, Retaining Retaining Retaining Ring, Retaining Reta
42 30590A Washer, Flat 43 32425 Rod Assy., Governor 44 31948 Spool, Governor 45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650714 Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 1-3/4" (Use as requi red)
43 32425 44 31948 5pool, Governor 45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650628A Screw, 5/16-18 x 2-3/8" (Use as required) 51 650714 Screw, 5/16-18 x 2-1/4" (Use as required) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as required) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as required) 51 650603 Screw, 5/16-18 x 1-3/4" (Use as required) 51 650603
44 31948 Spool, Governor 45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as required)
45 29193 Ring, Retaining 46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650695A Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 5/8" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d)
46 31947 Gear Assy., Governor 47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650714 Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 5/8" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as required)
47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as required) 51 650628A Screw, 5/16-18 x 2-1/4" (Use as required) 51 650695A Screw, 5/16-18 x 1-5/8" (Use as required) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as required) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as required) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as required) 51 650603 Screw, 5/16-18 x 5/8" (Use as required)
47 31930 Shaft, Mechanical Governor 48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as required) 51 650628A Screw, 5/16-18 x 2-1/4" (Use as required) 51 650695A Screw, 5/16-18 x 1-5/8" (Use as required) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as required) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as required) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as required) 51 650603 Screw, 5/16-18 x 5/8" (Use as required)
48 32000A * Gasket, Cylinder head 49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650695A Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d)
49 33034 Head, Cylinder 51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650603 Screw, 5/16-18 x 1-3/4" (Use as requi red) 52 Screw, 5/16-18 x 1-3/4" (Use as requi red) 53 Screw, 5/16-18 x 1-3/4" (Use as requi red) 54 Screw, 5/16-18 x 1-3/4" (Use as requi red) 55 Screw, 5/16-18 x 5/8" (Use as required)
51 650694A Screw, 5/16-18 x 2" (Use as required) 51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d)
51 650711 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650628A Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as required)
51 650628A Screw, 5/16-18 x 2-3/8" (Use as requi red) 51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d)
51 650695A Screw, 5/16-18 x 2-1/4" (Use as requi red) 51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as required)
51 650714 Screw, 5/16-18 x 1-5/8" (Use as requi red) 51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as required)
51 650697A Screw, 5/16-18 x 2-1/2" (Use as requi red) 51 650692 Screw, 5/16-18 x 1-3/4" (Use as requi red) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d)
51 650692 Screw, 5/16-18 x 1-3/4" (Use as required) 51 650603 Screw, 5/16-18 x 5/8" (Use as require d)
51 650603 Screw, 5/16-18 x 5/8" (Use as require d)
51 650603 Screw, 5/16-18 x 5/8" (Use as require d)
$^{\prime}$
1 Tooloto Opan i lag (10 00)
53 34251 Resistor Spark Plug (RJ-17LM)
· ·
55 28537 Washer, Plain
57 650691 Washer, Flat (Use as required)
58 650690 Washer, Belleville (Use as required)
58 8274 Washer, Lock (Use as required)
59 650128 Screw, 10-24 x 1/2"
60 31976 Extension, Blower housing
61 31978 Bracket, Fuel tank
63 410144B Fuel Cap (White Plastic)(Std.)(As req uired)
63 34210 Fuel Cap (Red Plastic) (Spurt resistant, High profile) (Use
required)
67 650517 Screw, 1/4-20 x 27/32" (Use as requir ed)
67 650561 Screw, 1/4-20 x 5/8" (Use as required)
67 30063 Screw, 1/4-20 x 1/2" (Use as required)
67 792028 Screw, 5/16-18 x 7/8" (Use as require d)
71 26460 Clamp, Fuel line (Use as required)
72 29774 Fuel Line (Braided) (8.25") (Use as r equired)
72 30705 Fuel Line (Braided) (16") (Use as req uired)
72 30962 Fuel Line (Braided) (32") (Use as req uired)
72 30965 Fuel Line (Braided) (48") (Use as req uired)
73 32579 Baffle, Blower housing
74 650561 Screw, 1/4-20 x 5/8"
,
\mathbf{O}^{\prime}
79 31928 Cup, Bearing
80 32031 Spacer, Steel (.010" thick) NOTE: Determine the gap
between the cover and the machined surface on the cylind
which can be from .001"up to .007" in which case no shin
gaskets will be required. Use of gasket must be limited to
combined total of .010" thick. Steel spacersmust be use
as required .

Pof #	Part Number Qty	Description
	31971 Qty	* Gasket, Shim (.004/.005 thick) NOTE: Determine the gap between the cover and the machined surface on the cylinder which can be from .001"up to .007" in which case no shim gaskets will be required. Use of gasket must be limited to a combined total of .010" thick. Steel spacersmust be used as req
82	31972	* Gasket, Shim (.005/.007 thick) NOTE: Determine the gap between the cover and the machined surface on the cylinder which can be from .001"up to .007" in which case no shim gaskets will be required. Use of gasket must be limited to a combined total of .010" thick. Steel spacersmust be used as req
	32599 32577	"O" Ring Cover, Cylinder NOTE: Determine the gap between the cover and the machined surface on the cylinder which can be from .001"up to .007" in which case no shim gaskets will be required. Use of gasket must be limited to a combined total of .010" thick. Steel spacersmust be used as required to eliminat
84 85 86 87 91 92 95 96 98 99 100 101 102 103 104 105 106 107 108 109 112 113 114 115 120 121 122E 123 125A 126	650679 792028 650666 650594 33044A 8274 650595 8274 650624 31958 31957 35350 650128 28558 31966 31984A 650597 650591 33099 32042 34238 33038 29752 650587 27272 650399 30767 32377 31925 31926 650513 650713	Lockwasher, 5/16" (Use as required) Screw, 5/16-18 x 7/8" Washer, Lock Nut, Flywheel, 3/4-16 Blower Hsg. (Incl.73) (For electric s tarter) Washer, Lock Screw, 5/16-24 x 3/8" Washer, Lock Screw, 5/16-24 x 9/16" * Gasket, Breather Breather Assy. Tube, Breather Screw, 10-24 x 1/2" Washer, Wave Bushing, Control lever Lever, Control Screw, 10-24 x 5/8" Screw, 10-24 x 2" Spring Nipple, Exhaust pipe Muffler Plug, Button (Use as required) Nut & Lockwasher Assy. Stud, Carburetor * Gasket, Air cleaner Screw, 10-32 x 5/8" Spacer, Air cleaner Bracket, Air cleaner Element, Air cleaner Cover, Air cleaner Nut, Wing Screw, 5/16-18 x 5/8" (Use as require d)
128 141 141A	650429 792028 26073 8274 31960	Screw, 5/16-18 x 3/4" (Use as require d) Screw, 5/16-18 x 7/8" (Use as require d) Washer, Flat (Use as required) Lockwasher, Split (Use as required) * Gasket, Carburetor

www.mymowerparts.com

For Discount Tecumseh Engine Parts Call 606-678-9623 or 606-561-4983 $\,$ Page 5 of 9 Engine Parts List #1


		Qty Description
147	31959	Baffle, Air
	33356	Terminal, Ground
	730201	Trigger Pin Kit (Use as required)
173	610118	Cover, Spark plug (Use as required)
	32426	Spacer, Screen
	650675	Washer, Flat 1/4"
	8345	Washer, 1/4 plain (Use as required)
	27070	Washer, Lock 1/4 E.T. (Use as require d)
	650675	Washer, Flat 1/4 (Use as required)
	27793	Clip, Conduit
	28942	Screw, 10-32 x 3/8"
	650713	Screw, 5/16-18 x 5/8"
	26073	Washer, Flat
	32154	Cap, Pipe
	32673	Nipple, Pipe
	33776	Screen, Starter pulley
	650670	Screw, 1/4-20 x 3/4"
	32046	Rope Assy., Starter (Use as required)
	650661	Screw, 1/4-20 x 3/4"
	610408	Nut, Hex
	610750	Grommet, Lead wire
	610748	Solid State Magneto (Incl.151,173,265,266)
	610746	Solid State Flywheel
	32730	Decal, Craftsman
	34768	Decal, Name
	31752	Decal, Air cleaner
	34346	Decal, Instruction
	32411A	Valve, Seat, Spring & Gasket Assy.
301	631304A	Carburetor (Incl. 145) (Refer to Division 5, Section A, page 94 for breakdown)
304	33237A	* Gasket Set (Incl. items marked *)



www.mymowerparts.com

For Discount Tecumseh Engine Parts Call 606-678-9623 or 606-561-4983 $\,$ Page 7 of 9 Engine Parts List #2

	Part Number	Qty	Description
	27070		Washer, Lock 1/4 E.T. (Use as require d)
	650675		Washer, Flat 1/4 (Use as required)
	650701		Screw, 8-18 x 7/16" (Use as required)
	792028		Screw, 5/16-18 x 7/8" (Use w/32817 st r.motor)
	650781		Screw,5/16-18 x 11/16"(Use w/33835 st r.motor)
235	34276		Plate, Cover (Use as required to cover regulator mounting hole in blower housing)
236	650736		Screw, 10-16 x 3/8" (Use as required)
252	730134		Rewind Starter Kit (Incl. 165, 166, 167, 168, 169 & 291) (Use as required)
253	33018		Harness Assy., Adapter (Use as requir ed)
254	610761		Alternator Coil (Solid State) (10 Amp) (Incl. Nos. 253, 256 & 257A)
255	650416		Screw, 10-32 x 1"
256	610922		Terminal, Female
257B	610824		Flat Connector (Female terminals) (As req.)
257A	610819		Connector, Pyramid (For female termin als)
266	610750		Grommet, Lead wire
268	610749		Solid State Regulator (10 Amp)
275	730198		Starter Switch Kit(Incl. 287-298) (As req.)
303	33835		Electric Starter Motor (12 Volt) NOTE: The 32817 and 33835 starter motors are used interchangeably on the se models. Refer to service numberstamped on end cap of motor, or on decal for identification. Refer to Division 5, Section D for breakdown.



www.mymowerparts.com

For Discount Tecumseh Engine Parts Call 606-678-9623 or 606-561-4983 $\,$ Page 9 of 9 Engine Parts List #3

Ref #	Part Number (Oty Description
41	31967	Spring, Governor
70G	32961	Valve, Fuel shut-off
71	26460	Clamp, Fuel line (Use as required)
72	29774	Fuel Line (Braided) (8.25") (Use as r equired)
72	30705	Fuel Line (Braided) (16") (Use as req uired)
72	30962	Fuel Line (Braided) (32") (Use as req uired)
72	30965	Fuel Line (Braided) (48") (Use as req uired)
111	650590	Nut, Conduit
119	28534	Pipe Plug, 1/8-27 (Use as required)
119	9556	Plug, Pipe, 1/8-27 (Use as required)
122	32919	Bracket, Air cleaner
160	32920	Elbow, Air cleaner
161	650416	Screw, 10-32 x 1" (two required)
	650583	Washer, Plain
163	28788	Screw, 8-32 x 1/2"
172	31990	Bracket, Choke control
184	27793	Clip, Conduit
185	28942	Screw, 10-32 x 3/8"
237	32958	Fitting, Fuel
	32959	Fuel Pump, Impulse
	33010	Repair Kit, Impulse fuel pump
285	32960	Washer, Lock
286	650849	Nut, Hex jam, 3/8-24