


ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.

VIEW 1 OF 2











Engine Parts List #1

Ref #	Part Number	Qty	Description
1	0	1	Cylinder (Order S/B if replacement is needed)
20	510319	1	Oil Seal
24	530110	1	Ball Bearing
29A	530104A	1	Cartridge Bearing
29	530150	1	Needle Bearing & Liner Set (37 Needle s)
30	290553	1	Crankshaft
33	330177	1	Adapter Plate
34	650797	4	Screw, 5/16-18 x 1/2"
41	310283A	1	Piston & Pin Ass'y. (Incl. 43)
42	310190	2	Ring Set
43	310167	2	Piston Pin Retaining Ring
45	310235B	1	Connecting Rod Ass'y. (Incl. 29, 29A & 46)
46	650633	2	Connecting Rod Bolt
69	510292A	1	* Cylinder Cover Gasket
75	28427	1	Oil Seal
77	780097	1	Cartridge Bearing
89A	611032	1	Adapter Sleeve
90	611112	1	Flywheel
92	650815	1	Belleville Washer
93	650390	1	Flywheel Nut
100	34443B	1	Solid State Ignition
101	610118	1	Spark Plug Cover
103	651007	2	Screw, Torx T-15, 10-24 x 15/16"
110	611031	1	Ground Wire
119	510274A	1	* Cylinder Head Gasket
120	250240B	1	Cylinder Head
122	570641	1	Retaining Ring
130	650477	6	Screw, Torx T-30, 1/4-20 x 3/4"
135	33636	1	Resistor Spark Plug (RJ17LM)
169	510323A	1	* Cover Plate Gasket
170	470152A	1	Reed & Cover Plate (Incl. 178)
174	650579	4	Screw, Torx T-25, 10-24 x 1/2"
178	29752	2	Nut & Lock Washer, 1/4-28
184	510110A	1	* Carburetor Gasket
220	570640	1	Control Knob
238	650806	2	Screw, 10-32 x 5/8"
240	450234	1	Air Cleaner Body
245	450236	1	Air Cleaner Filter
245B	450235	1	Air Cleaner Filter
250	33007	1	Air Cleaner Cover
257	650911	4	Screw, Torx T-30, 1/4-20 x 5/8"
258	350409	1	Blower Housing Base (Incl. 20)
260	350457	1	Blower Housing
261	650958	3	Screw, 1/4-20 x 7/16"
261B	650854	1	Washer
261C	650773	1	Screw, 1/4-20 x 1/2"
274	510314A	1	Exhaust Gasket
275	390300	1	Muffler
277	650911	2	Screw, Torx T-30, 1/4-20 x 5/8"
287	650926	4	Screw, 8-32 x 21/64"
290	34357	1	Fuel Line
292	26460	2	Fuel Line Clamp
298	650803	2	Screw, 10-32 x 7/8"
300	410241	1	Fuel Tank (Incl. 301)
301	410238	1	Fuel Cap
370H	550214	1	Choke Decal
370A	36261	1	Lubrication Decal
370	550212	1	Fuel Mix Decal

Ref #	Part Number	Qty	Description
370K	36695	1	Starter Decal
370I	550213	1	Warning Decal
380	632335	1	Carburetor (Incl. 184)
390	590732	1	Rewind Starter (NOTE: This engine could have been built with 590738 starter. Refer to the design of the rope pulley strength ribs for part identification. Individual starter parts do not interchange. Refer to service bulletin 116.)
400	510295A	1	* Gasket Set (Incl. items marked PK i n notes) (Incl. one each of part #'s: 510110A, 510217A, 510227A, 510268A, 510270A, 510274A, 510292A, 510323A)
420	730227A	1	2-Cycle Oil (8 oz.)

ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.

VIEW 2 OF 2



Ref #	Part Number	Qty	Description
92	650815	1	Belleville Washer
93	650390	1	Flywheel Nut
230	34338	1	Air Cleaner Gasket
238	650806	2	Screw, 10-32 x 5/8"
240	450234	1	Air Cleaner Body
245B	450235	1	Air Cleaner Filter
245	450236	1	Air Cleaner Filter
248	33008	1	Air Cleaner Tube
250	33007	1	Air Cleaner Cover
261B	650854	1	Washer
285	590551A	1	Starter Cup
326	450237	1	Plug
370H	550214	1	Choke Decal
370I	550213	1	Warning Decal
370K	36695	1	Starter Decal