



24A-672G066 Jet Sweep Blower (2007)
General Assembly



24A-672G066 Jet Sweep Blower (2007)
General Assembly

Page 2 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	710-04605	1		TT Screw, 5/16-18 x 1.50
2	781-04175	1		Chute Plate
3	710-0487	1	/P	Carriage Screw, 5/16-18 x 2.00
4	710-1220	1	/P	Screw, #12-16 x .750
5	720-04072	1	S	Star Knob
6	720-04091	1		Foam Grip
7	736-0451	1	S	Saddle Washer, .320 x .93 x .060
8	749-04291	1		Upper Handle
9	749-04292	1	S	Lower Handle
10	710-0237	1	/P	Screw, 5/16-24 x .625
11	710-04705	1		Screw, #12-16 x .750
12	710-3008	1	/P	Screw, 5/16-18 x .75
13	712-04035	1		Hexlock Nut, #8-32
14	712-04063	1	/P	Flange Lock Nut, 5/16-18
15	712-04064	1	/P	Flange Lock Nut, 1/4-20
16	720-0426	1	/P	Knob
17	731-05644	1		Louver Plate
18	732-3042	1		Compr. Sprng., .515 x .641 x .95
19	736-0242	1	/P	Bell Washer, .340 x .872 x .060
20	738-04222	1		Shoulder Scr., .437 x .13, 1/4-20
21	738-04223	1		Shoulder Scr., .18 x 4.8, 8-32
22	781-04165	1		Back Plate
23	781-04181	1		Louver Lever
24	781-04212	1	S	Louver Guide Plate
25	731-05592	1		Blower Housing
26	681-04067	1	S	Frame Assembly
27	710-0654A	1	/P	TT Screw, 3/8-16 x 1.00
28	631-04213	1		Impeller Assembly
29	710-1254	1	/P	Screw, 3/8-24 x 2.25
30	736-0217	1	S	Washer, Lock, 3/8
31	731-05664	1		Blower Cover
32	712-04065	1	/P	Flange Lock Nut, 3/8-16
33	726-0299	1	/P	Push Cap
34	734-04019	1		Wheel, 12 x 2.125
35	734-04033	1	/P	Wheel, 8 x 2
36	736-0504	1	S	Washer, Wave, .510 x .750 x .017
37	738-0213	1	/P	Shoulder Screw, .498 Dia. X 1.44
38	631-04253	1		Chute Attachment



24A-672G066 Jet Sweep Blower (2007)
Quick Reference

Page 4 of 4

Ref #	Part Number	Qty	S/P/F	Description
	759-3336	1	/P	Spark Plug
	BS-493537S	1	/P	Pre Filter
	BS-491588S	1	/P	Air Filter
	BS-298090S	1	/P	Fuel Filter
	720-04091	1		Foam Grip
	720-0426	1	/P	Height Adjustment Knob
	720-04072	1	S	Handle Knob
	734-04019	1		Wheels
	734-04033	1	/P	Front Caster Wheel
	726-0299	1	/P	Push Cap (Wheel)