


Ref #	Part Number	Qty	S/P/F	Description
1	753-05206	1		Engine Cover Assembly (includes 2 & 3)
2	753-04595	1	S	Cover Screw
3	753-05377	1	S	Screw
4	753-05209	1		Rocker Cover
5	753-05210	1	S	Rocker Cover O-Ring
6	753-05228	1		Cylinder Assembly (includes 3, 5 & 9)
7	753-05229	1		Piston Ring Assembly
8	753-05230	1		Piston Assembly (includes 7)
9	753-05232	1		Cylinder O-Ring
10	791-182379	1	/P	Breather Hose
11	753-05408	1	/P	Oil Plug (includes 12)
12	791-182290	1		Oil Plug O-Ring
13	753-05237	1		Crankcase Cover
14	753-05238	1		Crankcase Cover O-ring
15	753-05503	1	/P	Crankcase Assembly (includes 9, 10, 14 & 16)
16	753-05240	1	/P	Flywheel Assembly
16	914-04016	1	/P	Woodruff Key .125 x .375 Not shown
17	753-05241	1		Cam Bracket Assembly (includes 18)
18	753-05242	1	S	Cam Bracket Screw
19	753-05504	1		Lead Wires
20	753-05243	1	S	Module Assembly
21	753-05244	1		Muffler Gasket
22	753-05245	1		Muffler Assembly (includes 21 & 23)
23	753-05246	1	S	Muffler Screw
24	753-05255	1		Spark Plug
25	753-05247	1		Insulator Gasket
26	753-05248	1	S	Nut
27	753-05249	1		Insulator (includes 28)
28	753-05366	1	/P	Carburetor Gasket
29	753-05251	1		Carburetor w/Primer
30	753-04030	1		O-Ring
31	753-05507	1	S	Air Filter Mounting Screw
32	753-05505	1		Air Cleaner Cover Assembly (includes 33, 34 & 37-39)
33	791-182097	1		Breather Tube
34	791-181000	1		Grommet Washer
35	791-182409	1		Washer
36	753-05248	1	S	Nut
37	753-182657	1		Air Filter Plate
38	753-05506	1		Air Filter
39	791-182659	1		Air Filter Cover
40	753-05256	1	/P	Fuel Tank Assembly w/Fuel Lines (includes 41)
41	753-1229	1		Fuel Cap
42	753-05259	1		Fuel Tank Pads
43	753-05260	1	S	Push Nut
44	753-1202	1		Pressure Plate Screw
45	753-05074	1		Pressure Plate (includes 44)
46	753-05078	1	S	Spacer
47	753-05508	1		Starter Assembly (includes 48)
48	753-05509	1		Rope

25A-515-966 TBE515 (2007)
 Engine Assembly Oct.2007 & After

Page 3 of 10

Ref #	Part Number	Qty	S/P/F	Description
49	753-04286	1		Recoil Spring
50	791-181079	1	S	Handle
51	791-611061	1		Rope Guide
52	753-05510	1		Starter Housing Assembly (includes 3 & 43-51)
53	791-182396	1	S	Washer
54	756-04269	1	/P	Drive Shaft Pulley
55	746-04354	1		Throttle Cable
	753-05297	1	/P	Spark Arrestor Assembly Items Not Shown
	753-05511	1		Shortblock Assembly (includes 3-12, 14, 15, 17 & 24) Items Not Shown

25A-515-966 TBE515 (2007)
Engine Assembly Oct.2007 & Before




Ref #	Part Number	Qty	S/P/F	Description
1	753-05206	1		Engine Cover Assembly (includes 2 & 3)
2	753-04595	1	S	Cover Screw
3	753-05377	1	S	Screw
4	753-05209	1		Rocker Cover
5	753-05210	1	S	Rocker Cover O-Ring
6	753-05228	1		Cylinder Assembly (includes 3, 5 & 9)
7	753-05229	1		Piston Ring Assembly
8	753-05230	1		Piston Assembly (includes 7)
9	753-05232	1		Cylinder O-Ring
10	791-182379	1	/P	Breather Hose
11	753-05236	1	S	Oil Plug (includes 12)
12	791-182290	1		Oil Plug O-Ring
13	753-05237	1		Crankcase Cover
14	753-05238	1		Crankcase Cover O-ring
15	753-05503	1	/P	Crankcase Assembly (includes 9, 10, 14 & 16)
16	753-05240	1	/P	Flywheel Assembly
16	914-04016	1	/P	Woodruff Key.125 x .375 Not shown
17	753-05241	1		Cam Bracket Assembly (includes 18)
18	753-05242	1	S	Cam Bracket Screw
19	753-05504	1		Lead Wires
20	753-05243	1	S	Module Assembly
21	753-05244	1		Muffler Gasket
22	753-05245	1		Muffler Assembly (includes 21 & 23)
23	753-05246	1	S	Muffler Screw
24	753-05255	1		Spark Plug
25	753-05247	1		Insulator Gasket
26	753-05248	1	S	Nut
27	753-05249	1		Insulator (includes 28)
28	753-05366	1	/P	Carburetor Gasket
29	753-05251	1		Carburetor w/Primer
30	753-04030	1		O-Ring
31	753-05507	1	S	Air Filter Mounting Screw
32	753-05505	1		Air Cleaner Cover Assembly (includes 33, 34 & 37-39)
33	791-182097	1		Breather Tube
34	791-181000	1		Grommet Washer
35	791-182409	1		Washer
36	753-04993	1	S	Nut
37	753-182657	1		Air Filter Plate
38	753-05506	1		Air Filter
39	791-182659	1		Air Filter Cover
40	753-05256	1	/P	Fuel Tank Assembly w/Fuel Lines (includes 41)
41	753-1229	1		Fuel Cap
42	753-05259	1		Fuel Tank Pads
43	753-05260	1	S	Push Nut
44	753-1202	1		Pressure Plate Screw
45	753-05074	1		Pressure Plate (includes 44)
46	753-05078	1	S	Spacer
47	753-05435	1	/P	Starter Assembly (includes 48)
48	753-05509	1		Rope

25A-515-966 TBE515 (2007)
 Engine Assembly Oct.2007 & Before

Page 6 of 10


Ref #	Part Number	Qty	S/P/F	Description
49	753-04286	1		Recoil Spring
50	791-181079	1	S	Handle
51	791-611061	1		Rope Guide
52	753-05262	1		Starter Housing Assembly (includes 3 & 43-51)
53	791-182396	1	S	Washer
54	756-04269	1	/P	Drive Shaft Pulley
55	746-04354	1		Throttle Cable
	753-05297	1	/P	Spark Arrestor Assembly Items Not Shown
	753-05511	1		Shortblock Assembly (includes 3-12, 14, 15, 17 & 24) Items Not Shown



Ref #	Part Number	Qty	S/P/F	Description
1	753-05563	1		Handle Assembly (includes 2-7)
2	753-05517	1	S	Throttle Trigger
3	753-05518	1	S	Throttle Trigger Spring
4	753-05515	1	S	Blade Lockout Lever
5	753-05522	1	S	Switch Assembly
6	753-05523	1		Upper Handle Screw & Nut Assembly
7	731-05859	1	/P	Throttle Lever
	746-04354	1		Throttle Cable (not shown)
8	753-05524	1		Starter Rope Guide Assembly
9	753-05558	1		Middle Handle Assembly (includes 10)
10	753-05526	1		Middle Handle Screw & Nut Assembly
11	753-05557	1	S	Lower Handle
12	753-05528	1	S	Lower Handle Screw & Nut Assembly
13	753-05561	1	S	Clutch Cable
14	753-05539	1		Edger Frame
15	753-05525	1	S	Lock Nut
16	753-05530	1	S	Wheel
17	753-05529	1	S	Wheel Bolt
18	753-05556	1	S	Spacer
19	753-05538	1	S	Spacer Screw
20	753-05531	1	S	Height Adjustment Lever Assembly
21	753-05532	1	S	Washer
22	753-05534	1	S	Shoulder Screw
23	753-05535	1	S	Nut
24	753-05533	1	S	Washer
25	753-05536	1	S	Pivot Arm
26	753-05537	1	S	Height Adjustment Spacer
27	753-05538	1	S	Spindle Plate Screw
28	753-05559	1	S	Spindle Spacer
29	753-05528	1	S	Screw
30	753-05553	1	S	Belt Retainer
31	753-05540	1		Idler Pulley Assembly
32	753-05541	1	S	Shoulder Screw
33	753-05560	1	S	Belt
34	753-05554	1	S	Screw
35	753-05555	1	S	Washer
36	753-05542	1	S	Pulley
37	753-05543	1		Blade Spindle
38	753-05544	1		Spindle Plate
39	753-05550	1	S	Bearing
40	753-05545	1	S	Bearing Cup
41	753-05546	1	S	Washer
42	753-05547	1	S	Blade Guard
43	753-05548	1	S	Screw
44	753-05562	1	S	Edger Blade
45	753-05549	1	S	Nut
46	753-04595	1	S	Screw
47	731-05822	1	/P	Belt Cover

25A-515-966 TBE515 (2007)
Quick Reference

Page 9 of 10



25A-515-966 TBE515 (2007)
Quick Reference

Page 10 of 10

Ref #	Part Number	Qty	S/P/F	Description
	753-05255	1		Spark Plug
	N/A	1		Pre Filter
	753-05506	1		Air Filter
	791-181775	1		Fuel Filter
	753-05560	1	S	Drive Belt
	731-05064	1	/P	Belt Guard
	753-05562	1	S	Blade
	N/A	1		Control Cable
	N/A	1		Drive Cable
	N/A	1		Knob
	N/A	1		Level Control
	N/A	1		Wheel Assembly (Font)
	N/A	1		Wheel Assembly (Rear)