


TB10CS 41BDT10G966  
Boom and Trimmer




TB10CS 41BDT10G966  
Boom and Trimmer

Page 2 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	753-04829	1		Throttle Housing Assembly (includes 2-4)
2	791-182405	1	/P	Switch
3	791-182690	1		Throttle Trigger Spring
4	753-04119	1	/P	Throttle Trigger
5	753-04917	1		Throttle Housing Screws
6	753-04466	1		Anti-Rotation Screw
7	753-04405	1	S	Throttle Cable
8	753-04830	1		Flexible Drive Shaft
9	753-04831	1		Drive Shaft Housing Assembly (includes 8)
10	791-153064	1	/P	D-Handle Assembly (includes 11)
11	791-153317	1	S	D-Handle Hardware
12	753-04282	1		Guard Mounting Hardware
13	753-04283	1		Guard (includes 14)
14	791-180553	1		Blade Assembly
15	753-04284	1		Outer Reel w/Retainer
16	791-610317B	1	/P	Spring
17	791-610318	1	S	Inner Reel
18	791-153066B	1	/P	Bump Knob
	791-153577B	1	/P	Inner Reel and Line (Optional - not shown)

TB10CS 41BDT10G966  
Engine

Page 3 of 5



TB10CS 41BDT10G966  
Engine

Page 4 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	753-04511	1	/P	Air Cleaner Cover Assembly (includes 2 & 36)
2	791-180350B	1	/P	Air Cleaner Filter
3	791-180351	1		Carburetor Mounting Screw Assembly
4	791-180226	1	S	Wavy Washer
5	791-182202	1	/P	Choke Knob w/screw
6	753-04418	1	/P	Choke Lever Assembly (includes 5)
7	753-04419	1	/P	Choke Plate Assembly (includes 6)
8	753-05153	1		Carburetor Assembly (includes 9)
9	791-610675	1		Carburetor Gasket
10	791-181860	1		Carb Mount Screw
11	791-683974B	1	/P	Primer & Hose Assembly
12	753-1196	1	/P	Carb Mount Assembly (includes 10, 13 & 14)
13	791-684451	1		Reed Assembly
14	753-1208	1	/P	Carburetor Mount Gasket
15	753-04321	1		Crankcase Service Assembly (includes 10)
16	791-612134	1		Rear Mounting Pad
17	753-04307	1	/P	Fuel Tank Assembly (includes 18-20)
18	791-182529	1		Fuel Cap Assembly
19	791-181086	1	/P	Fuel Return Line
20	753-04233	1		Fuel Line Assembly
21	791-145308	1		Front Mounting Pad
22	753-05091	1	/P	Shroud Extension & Stand (includes 36)
23	791-182736	1	S	Flywheel Assembly
24	791-610303	1		Spacer
25	753-04459	1	/P	Recoil Pulley Assembly (includes 28 & 30)
26	753-04286	1		Recoil Spring
27	753-1200	1		Rope Guide
28	753-04288	1	/P	Pulley Retainer
29	791-181079	1	S	Pull Handle
30	791-613103	1		Rope
31	753-1201	1	S	Pressure Plate Assembly (includes 32)
32	753-1202	1		Plate Screw
33	753-04887	1		Starter Housing Assembly (includes 25-32, 34 & 36)
34	791-181862	1	/P	Housing Screw
35	753-05155	1		Clutch Cover Assembly (includes 36-39)
36	791-181345	1	/P	Cover Screw
37	753-04466	1		Anti-Rotation Screw
38	753-04003	1		Clamping Screw
39	791-180217	1	S	Clamping Nut
40	753-05025	1	/P	Wire Leads and Sleeve
41	791-611063	1	/P	Ground Tab
42	753-04336	1		Module Assembly
43	791-610311B	1	/P	Spark Plug
44	753-05169	1	/P	Muffler Assembly (includes 45, 46 & Spark Arrestor)
45	753-04619	1	/P	Exhaust Gasket
46	753-04620	1	S	Muffler Mounting Bolts
47	753-04814	1	/P	Cylinder Assembly (includes 49 & 50)
48	753-04367	1	/P	Piston and Rod Assembly
49	753-04182	1		Cylinder Gasket
50	791-182723	1		Cylinder Bolt

TB10CS 41BDT10G966  
Engine

Page 5 of 5

Ref #	Part Number	Qty	S/P/F	Description
	753-1209	1		Piston Ring Set not shown
	753-04826	1		Short Block Assembly (includes 10, 15 & 47) not shown