



TB20CS TUFFY 41BDT20C966
Boom & Trimmer



TB20CS TUFFY 41BDT20C966
Boom & Trimmer

Page 2 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	753-04234	1		Throttle Housing Assembly (includes 2-4)
2	791-182405	1	/P	Switch
3	753-04119	1	/P	Throttle Trigger
4	791-182690	1		Throttle Trigger Spring
5	753-04405	1	S	Throttle Cable
6	753-04344	1	/P	Upper Drive Shaft Housing Assembly
7	791-153064	1	/P	D-Handle (includes 8)
8	791-181587	1	/P	D-Handle Hardware
9	753-1190	1	/P	Split Boom Coupler (includes 10-13)
10	791-182057	1		Screw
11	791-181617	1		Bolt
12	791-181981	1		Adjustment Knob (includes 13)
13	753-04386	1	S	Knob Retaining Nut
14	753-04508	1		Lower Drive Shaft Housing Assembly
15	753-04282	1		Guard Mounting Hardware
16	753-04283	1		Guard Assembly (includes 17)
17	791-180553	1		Blade Assembly
18	753-04284	1		Outer Spool Assembly (includes 19)
19	791-610660	1		Retainer
20	791-610317B	1	/P	Spring
21	753-1155	1	/P	Inner Reel
22	791-153066B	1	/P	Bump Head Knob Assembly
	753-1156	1	S	Reel and Line Assembly Items Not Shown, Optional



TB20CS TUFFY 41BDT20C966
Engine Parts

Page 4 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	753-04511	1	/P	Air Cleaner Cover Assembly (includes 2 & 38)
2	791-180350B	1	/P	Air Cleaner Filter
3	791-180351	1		Carburetor Mounting Screw Assembly
4	791-180226	1	S	Wavey Washer
5	791-182202	1	/P	Choke Knob w/Screw
6	753-04418	1	/P	Choke Lever (includes 5)
7	753-04419	1	/P	Choke Plate (includes 6)
8	753-05133	1		Carburetor Assembly (includes 9 & 19)
9	791-610675	1		Carburetor Gasket
10	791-181860	1		Carb Mount Screw
11	791-683974B	1	/P	Primer & Hose Assembly
12	753-1196	1	/P	Carb Mount Assembly (includes 10, 13 & 14)
13	791-684451	1		Reed Assembly
14	753-1208	1	/P	Carburetor Mount Gasket
15	791-612134	1		Rear Mounting Pad
16	753-04307	1	/P	Fuel Tank Assembly (includes 17-19)
17	791-182529	1		Fuel Cap Assembly
18	791-181086	1	/P	Fuel Return Line
19	753-04233	1		Fuel Line Assembly
20	791-145308	1		Front Mounting Pad
21	753-04409	1	S	Shroud Extension & Stand (includes 38)
22	753-05240	1	/P	Flywheel Assembly
22	914-04016	1	/P	Woodruff Key.125 x .375 Not shown
23	791-181525	1		Spacer
24	753-04459	1	/P	Recoil Pulley Assembly (includes 27 & 29)
25	753-04286	1		Recoil Spring
26	753-1200	1		Rope Guide
27	753-04288	1	/P	Pulley Retainer
28	791-181079	1	S	Pull Handle
29	791-613103	1		Rope
30	753-04417	1	/P	Pressure Plate Assembly (includes 31)
31	753-1202	1		Plate Screw
32	753-04402	1		Starter Housing Assembly (includes 24-31, 33 & 38)
33	791-181862	1	/P	Housing Screw
34	791-182396	1	S	Clutch Washer
35	791-182369	1	S	Clutch Rotor Assembly Mfg date 09092007 and before
35	753-05722	1		Clutch Rotor Assembly Mfg date 09102007 and after
36	791-153592	1	/P	Clutch Drum Assembly Mfg date 09092007 and before
36	753-05723	1		Clutch Drum Assembly Mfg date 09102007 and after
37	753-04403	1		Clutch Cover Assembly (includes 38-41)
38	791-181345	1	/P	Cover Screw
39	791-182519	1		Anti-Rotation Screw
40	753-04003	1		Clamping Screw
41	791-180217	1	S	Clamping Nut
42	753-05025	1	/P	Wire Leads and Sleeve
43	791-611063	1	/P	Ground Tab

TB20CS TUFFY 41BDT20C966
Engine Parts

Page 5 of 5

Ref #	Part Number	Qty	S/P/F	Description
44	753-04336	1		Module Assembly
45	791-610311B	1	/P	Spark Plug
46	753-05169	1	/P	Muffler Assembly (includes 47, 48 & Spark Arrestor)
47	753-04619	1	/P	Exhaust Gasket
48	753-04620	1	S	Muffler Mounting Bolts
49	753-04814	1	/P	Cylinder Assembly (includes 51 & 52)
50	753-04367	1	/P	Piston and Rod Assembly
51	753-04182	1		Cylinder Gasket
52	791-182723	1		Cylinder Bolt
	753-1209	1		Piston Ring Set Not Shown
	753-04812	1	/P	Short Block Assembly (includes Crankcase, 10, 45 & 49-52) Not Shown