


TB22EC 41ADT22C966
Engine Assembly

Page 1 of 4




TB22EC 41ADT22C966
Engine Assembly

Page 2 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	753-06177	1		Rear Cover Assembly (Incl. Ref No. 2 & 34)
2	791-181345	1	/P	Cover Screw
3	791-181862	1	/P	Housing Screw
4	753-06174	1		O-Ring
5	753-06175	1		Flywheel Assembly
6	753-06247	1		Washer
7	753-06218	1		Spacer
8	753-06522	1		Starter Housing (Incl. Ref No. 3 & 13)
9	753-05860	1	/P	Clutch Assembly
10	753-06181	1		Clutch Cover (Incl. Ref No. 2)
11	753-06418	1		Muffler Assembly (Incl. Ref No. 12 & 33)
12	753-06419	1		Muffler Gasket
13	791-182366	1		U-shaped Nut
14	753-06183	1		Fuel Tank Assembly (Incl. Ref No. 15 & 16)
15	791-181930	1		Tank Screw
16	791-182612	1	/P	Fuel Cap
17	753-06303	1		Module Assembly
18	753-06193	1		Spark Plug
19	791-182723	1		Crankcase Bolt
20	753-06275	1		Crankcase O-Ring
21	753-06189	1		Insulator Assembly (Incl. Ref No. 22 & 23)
22	753-06184	1		Insulator O-Ring
23	753-06185	1		Carburetor O-Ring
24	753-06190	1		Carburetor
25	753-06415	1		Aircleaner Cover Assembly (Incl. Ref No. 26)
26	753-06417	1		Aircleaner Filter
27	753-06188	1		Throttle Cable
28	753-06187	1		Lead Wires
29	791-182519	1		Anti-rotation Screw
30	753-04003	1		Clamp Screw
31	712-0161	1	/P	Clamp Nut
32	753-06253	1		Air Cleaner Gasket
33	753-06294	1		Muffler Screw
34	791-182195	1		Rear Housing Screw
35	753-06173	1		Electric Starter Cover Assembly
36	753-06523	1		Short Block Assembly (Incl. Ref No. 4-7 & 17-20)
	49M2027P953	1	S	Electric Starter Optional, Not shown
	49MESCBP953	1		Power Start Bit Optional, Not shown
	737-04041	1	S	Oil-2 cycle 3.20 oz Bottle Optional, Not shown

TB22EC 41ADT22C966
General Assembly

Page 3 of 4



TB22EC 41ADT22C966
General Assembly

Page 4 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	753-04234	1		Throttle Housing Assembly (Incl. Ref No. 2-4)
2	791-182405	1	/P	Switch
3	753-04119	1	/P	Throttle Trigger
4	791-182690	1		Throttle Trigger Spring
5	753-04344	1	/P	Upper Shaft Housing Assembly
6	753-05461	1		D-Handle (Incl. Ref No. 7)
7	791-181587	1	/P	D-Handle Hardware Assembly
8	753-1190	1	/P	Split Boom Coupler (Incl. Ref No. 9-12)
9	791-182057	1		Anti-Rotation Screw
10	791-181617	1		Bolt
11	791-181618B	1	/P	Adjustment Knob
12	712-04018A	1	/P	Knob Retainer Nut
13	753-04508	1		Lower Shaft Housing Assembly
14	753-04282	1		Shield Mounting Hardware
15	753-04283	1		Shield Assembly (Incl. Ref No. 16)
16	791-180553	1		Blade Assembly
17	753-04284	1		Outer Spool Assembly (Incl. Ref No. 18)
18	791-610660	1		Retainer
19	791-610317B	1	/P	Spring
20	753-1155	1	/P	Inner Reel
21	791-153066B	1	/P	Bump Head Knob Assembly
	953-1156	1	/P	Reel & Line Assembly
	753-05778	1		Fixed Line Insert