


TB475SS 41BDT47C063
Boom And Trimmer Parts




TB475SS 41BDT47C063
Boom And Trimmer Parts

Page 2 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	753-04234	1		Throttle Housing and Trigger Assembly (includes 2 & 3)
2	753-04119	1	/P	Throttle Trigger
3	791-182690	1		Throttle Trigger Spring
4	791-182405	1	/P	Switch Assembly
5	791-180869	1		Deluxe D-Handle Assembly (includes 6-8)
6	791-182870	1		Handle Mount Hardware
7	791-182167	1		Deluxe D-Handle
8	791-182168	1		Bottom Clamp
9	753-1247	1	S	Upper Drive Shaft Housing Assembly
10	753-1190	1	/P	EZ-Link (TM) Coupler (includes 11-14)
11	791-182057	1		Screw
12	791-181617	1		Bolt
13	791-181981	1		Adjustment Knob
14	791-181886	1		Knob Retaining Nut
15	791-182388	1		Lower Drive Shaft Housing Assembly
16	791-181166	1		Lower Flexible Drive Shaft
17	791-153597	1		Lower Clamp Assembly (includes 18)
18	791-145569	1	/P	Anti-Rotation Screw
19	791-180547	1		Shield Mounting Hardware
20	753-1213	1	/P	Shield and Blade Assembly (includes 21)
21	791-181823	1		Blade Assembly
22	791-181566	1		Gearbox Assembly
23	791-181457	1		Outer Spool & Eyelet Assembly
24	791-181458	1		Retaining Ring
25	791-181561	1		Thrust Washer
26	791-181459	1		Small Spring
27	753-04257	1	/P	Slider
28	791-181532	1		E-Clip
29	791-181531	1		Spring
30	791-181462	1		Plunger
31	791-181463	1		C-Clip
32	791-181464	1	S	Inner Reel
33	791-181465	1		Large Spring
34	791-181467	1		Foam Seal
35	791-181468	1	S	Bump Head Knob Assembly (includes 33 & 34)
	791-180120	1	S	Replacement Line, 0.095 Diameter Optional Accessory; Not Shown
	753-04218	1		Reel and Line Assembly Optional Accessory; Not Shown
	791-682075	1	S	Shoulder Strap Assembly Optional Accessory; Not Shown

TB475SS 41BDT47C063
Engine Parts



TB475SS 41BDT47C063
Engine Parts

Page 4 of 5

Ref #	Part Number	Qty	S/P/F	Description
1	753-04083	1		Engine Cover
2	791-182339	1	S	Engine Cover Screws
3	791-181025	1		Valve Cover Screw
4	791-182098	1		Valve Cover
5	791-182099	1	/P	Valve Cover Gasket
6	791-182340	1		Rocker Adjustment Nut
7	791-182101	1	/P	Rocker Arm Pivot
8	791-182100	1		Rocker Arm
9	791-182341	1		Rocker Arm Stud
10	791-182103	1		Valve Spring Retainer
11	791-181038	1		Valve Spring
12	791-182102	1		Push Rod Guide
13	791-181033	1		Push Rod
14	791-182745	1	S	Cylinder Head (includes 9 & 12)
15	791-182344	1	S	Cylinder Screw
16	791-182345	1		Intake Baffle
17	791-182749	1		Carburetor Mount Gasket
18	791-181034	1	S	Nut
19	791-182347	1		Carburetor Mount (includes 18)
20	791-182348	1		Carburetor Mount Screw
21	791-182732	1	/P	Carburetor Gasket
22	753-04296	1		Carburetor with Primer
23	791-181751	1		O-Ring, Carburetor
24	753-04305	1	/P	Air Filter/Choke Cover Assembly (includes 27)
25	791-182097	1		Breather Tube
26	791-181750	1		Air Filter Mounting Screw
27	791-181757	1		Air Filter
28	753-04316	1	S	Air Filter Cover
29	753-1229	1		Fuel Cap
30	791-182352	1		Fuel Return Line
31	791-182353	1		Fuel Pick-Up Line with Filter
32	791-181080	1		Screw
33	791-182354	1		Washer
34	753-1230	1		Fuel Tank Assembly (includes 29-31)
35	791-182356	1		Fuel Tank Shield
36	753-1231	1		Throttle Cable
37	791-182358	1		Muffler Baffle
38	791-181048	1		Muffler Gasket
39	791-182359	1	/P	Muffler (includes 38, 40-42)
40	791-180890	1		Spark Arrestor Screen
41	791-181045	1		Screen Cover
42	791-181046	1		Screw
43	791-182361	1		Muffler Mounting Screw
44	753-04092	1		Muffler Cover
45	791-182804	1		Switch Wire Assembly
46	791-181247	1	S	Palnut
47	753-1199	1		Recoil Pulley
48	753-04286	1		Recoil Spring
49	791-182366	1		Nut Clip
50	791-181079	1	S	Pull Handle
51	791-611061	1		Rope Guide
52	791-613103	1		Rope

TB475SS 41BDT47C063
Engine Parts

Page 5 of 5

Ref #	Part Number	Qty	S/P/F	Description
53	791-181020	1		Starter Housing Screw
54	753-1237	1	S	Starter Housing Assembly (includes 46-52)
55	791-182368	1	S	Clutch Washer
56	753-1238	1		Clutch with Spacer
57	791-153592	1	/P	Clutch Drum
58	753-1239	1		Clutch Cover
59	791-145569	1	/P	Anti-Rotation Screw
60	753-1240	1		Screw
61	753-1241	1		Nut
62	791-181345	1	/P	Clutch Cover Screws
63	753-04298	1		Ignition Module with Screws
64	791-181065	1		Spacer
65	753-04299	1		Flywheel
66	791-182743	1	/P	Shroud Assembly w/Screws
67	791-182376	1	/P	Crankcase Assembly (includes 68 & 69)
68	791-182375	1		90° Elbow
69	791-182379	1	/P	Breather Hose
70	791-181015	1		Cam Gear
71	753-1242	1	S	Cam Follower Set
72	791-181013	1		Cam Bracket
73	791-181012	1		Cam Bracket Screw
74	791-181040	1		Valves, Intake and Exhaust
75	791-182374	1		Cylinder Gasket
76	791-181018	1		Oil Pan Gasket
77	791-182377	1		Oil Pan (includes 76 & 78)
78	791-181020	1		Oil Pan Screws
79	753-04041	1	S	Dipstick Assembly
80	791-182290	1		O-Ring
81	791-181009	1		Connecting Rod
82	791-181008	1		Wrist Pin Button
83	753-1243	1	S	Piston
84	791-181006	1		Wrist Pin
85	791-182295	1	S	Piston Ring Set
86	791-182409	1		Washer
87	791-181861	1		Screw
88	791-612468	1		Compression Spring
89	791-182537	1		Grommet
	791-180852B	1	/P	Spark Plug Parts not shown
	753-1245	1		Short Block Assembly (includes 3-15, 66-85); Parts not shown
	791-180142	1	S	Starter Pawl Repair Kit Parts not shown
	791-182156	1	S	Carburetor Repair Kit Parts not shown
	753-1248	1		Gasket Diaphragm Repair Kit Parts not shown