


TB70SS 41DDT70C966  
Engine Assembly




TB70SS 41DDT70C966  
Engine Assembly

Page 2 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	753-04511	1	/P	Air Cleaner Cover Assembly (Incl. Ref No.2 & 26)
2	791-180350B	1	/P	Air Cleaner Filter
3	791-180351	1		Carburetor Mounting Screw Assembly
4	936-0271	1	/P	Wavey Washer
5	791-182202	1	/P	Choke Knob w/Screw
6	753-04418	1	/P	Choke Lever (Incl. Ref No.5)
7	753-04419	1	/P	Choke Plate (Incl. Ref No.6)
8	753-05133	1		Carburetor Assembly (Incl. Ref No.9)
9	791-610675	1		Carburetor Gasket
10	791-181860	1		Carb Mount Screw
11	791-683974B	1	/P	Primer & Hose Assembly
12	753-1196	1	/P	Carb Mount Assembly (Incl. Ref No.10, 13 & 14)
13	791-684451	1		Reed Assembly
14	753-1208	1	/P	O-Ring
15	791-612134	1		Rear Mounting Pad
16	753-04307	1	/P	Fuel Tank Assembly (Incl. Ref No.17)
17	791-182529	1		Fuel Cap Assembly
18	791-145308	1		Front Mounting Pad
19	753-05091	1	/P	Shroud Extension & Stand (Incl. Ref No.26)
20	753-05240	1	/P	Flywheel Assembly
20	914-04016	1	/P	Woodruff Key.125 x .375 Not shown
21	791-181525	1		Spacer
22	753-05775	1		Starter Housing Assembly (Incl. Ref No.23 & 26)
23	791-181862	1	/P	Housing Screw
24	753-05860	1	/P	Clutch Rotor Assembly
25	753-04403	1		Clutch Cover Assembly (Incl. Ref No.26-29)
26	791-181345	1	/P	Cover Screw
27	791-182519	1		Anti-Rotation Screw
28	753-04003	1		Clamping Screw
29	791-180217	1	S	Clamping Nut
30	753-05025	1	/P	Wire Leads and Sleeve
31	791-611063	1	/P	Ground Tab
32	753-04336	1		Module Assembly (Incl. Ref No.31)
33	791-610311B	1	/P	Spark Plug
34	753-05169	1	/P	Muffler Assembly (Incl. Ref No.35, 36 & Spark Arrestor)
35	791-180680	1		Exhaust Gasket
36	710-04188A	1	/P	Muffler Mounting Bolts
37	753-04814	1	/P	Cylinder Assembly (Incl. Ref No.39 & 40)
38	753-04367	1	/P	Piston and Rod Assembly
39	753-04182	1		Cylinder Gasket
40	791-182723	1		Cylinder Bolt
	753-1209	1		Piston Ring Set Not Shown
	753-04812	1	/P	Short Block Assembly Not Shown (Incl. Ref No. Crankcase, 10, 33 & 37-40)

TB70SS 41DDT70C966  
General Assembly



TB70SS 41DDT70C966  
General Assembly

Page 4 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	753-04234	1		Throttle Housing Assembly (Incl. Ref No. 2-4)
2	753-04119	1	/P	Throttle Trigger
3	791-182690	1		Throttle Trigger Spring
4	791-182405	1	/P	Switch
5	746-04085A	1	/P	Throttle Cable Assembly
6	753-04344	1	/P	Upper Drive Shaft Housing Assembly
7	753-06039	1		Deluxe D-Handle Assembly (Incl. Ref No. 8)
8	753-06040	1		Bolt
9	753-1190	1	/P	Split Boom Coupler (Incl. Ref No.10-13)
10	791-182057	1		Screw
11	791-181617	1		Bolt
12	791-181981	1		Adjustment Knob (Incl. Ref No 13)
13	712-04018A	1	/P	Knob Retaining Nut
14	753-06139	1		Lower Drive Shaft Housing Assembly
15	753-05267	1		Lower Flexible Drive Shaft
16	7039	1	/P	Anti-Rotation Screw
17	753-06140	1		Gear Box Assembly (Incl. Ref No.16)
18	753-06125	1		Shield Mounting Screws
19	753-06123	1		Shield Assembly (Incl. Ref No.18 & 20)
20	753-06126	1		Blade Assembly
21	791-610327	1		Shoulder Strap Clip
22	753-04284	1		Outer Spool Assembly
23	791-610660	1		Retainer
24	791-610317B	1	/P	Spring
25	753-1155	1	/P	Inner Reel
26	791-153066B	1	/P	Bump Knob Assembly
	953-1156	1	/P	Reel & Line Assembly Not Shown
	791-682075B	1	/P	Shoulder Strap Not Shown
	753-05778	1		Fixed Line Insert Not Shown