


TBP6040 41AD604C966
Engine Assembly




TBP6040 41AD604C966
Engine Assembly

Page 2 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	753-06084	1		Aircleaner Assembly (includes 2 & 3)
2	753-06085	1		Air Filter
3	710-04517	1	/P	Screw
4	791-181751	1		Carburetor O-Ring
5	753-06083	1		Carburetor Assembly w/ Fuel Lines
6	791-181709	1		Carburetor Gasket
7	753-06103	1		Heat Sink
8	753-06082	1		Carburetor Baffle
9	791-181003	1	/P	Screw
10	753-05904	1		Insulator
11	753-05673	1		Insulator Gasket
12	712-04099	1	/P	Nut
13	753-06107	1		Engine Cover
14	791-181025	1		Screw
15	753-05901	1		Valve Cover
16	753-05902	1		Valve O-Ring
17	753-05910	1		Cylinder O-Ring
18	794-00042	1		Spark Plug
19	753-06081	1		Throttle Cable
20	753-06080	1		Muffler Assembly
21	753-05244	1		Muffler Gasket
22	710-04487	1	/P	Muffler Bolt
23	753-05907	1		Module Assembly
24	753-06086	1		Lead Wires
25	753-05400	1		Oil Plug Assembly
26	753-06087	1		Oil Fill Tube Assembly (includes 27)
27	710-04604	1	/P	Screw
28	753-05815	1		Flywheel
29	753-05814	1		Spacer
30	9162-1	1	/P	Clutch Washer
31	753-05860	1	/P	Clutch Assembly
32	753-06094	1		Clutch Cover Assembly
33	710-04604	1	/P	Screw
34	791-182519	1		Anti-rotation Screw
35	753-04291	1		Clamp Screw & Nut
36	753-06093	1		Fuel Tank (includes 37)
37	753-05289	1		Fuel Cap
38	753-05259	1		Fuel Tank Pad
39	753-06091	1		Pawl Assembly
40	753-06104	1		Electric Start Adapter
41	753-06108	1		Starter Cover Assembly
42	710-04194	1	/P	Screw
43	753-06101	1		Muffler Shield
44	753-06122	1		Carburetor Heat Shield
	753-06088	1		Short Block Assembly Not shown

TBP6040 41AD604C966
General Assembly



TBP6040 41AD604C966
General Assembly

Page 4 of 4

Ref #	Part Number	Qty	S/P/F	Description
1	753-05192	1		Throttle Housing Assembly (includes 2-5)
2	753-05517	1	S	Throttle Trigger
3	753-05007	1	/P	Spring
4	753-05171	1	S	Throttle Lock-out
5	791-182405	1	/P	Switch
6	791-610327	1		Shoulder Strap Clip
7	753-04236	1	/P	Upper Drive Shaft Housing Assembly
8	753-05008	1		D-Handle Assembly (includes 9 & 10)
9	753-05295	1		Barrier Bar Assembly
10	791-181070	1		Screw
11	753-04504	1	/P	Lower Drive Shaft Housing Assembly
12	753-05820	1		Shield Assembly (includes 13)
13	753-05821	1		Blade Assembly
14	753-05822	1		Screw
15	753-06089	1		Guard Mounting Bracket
16	791-182193	1	/P	Gearbox
17	791-182196	1		Gearbox Spacer
18	796-00033	1	S	Cutting Head Assembly
19	753-1190	1	/P	Split Boom Coupler (includes 20-23)
20	791-182057	1		Screw
21	791-181617	1		Bolt
22	791-181987	1		Adjustment Knob
23	753-04386	1	S	Knob Retaining Nut
24	753-05267	1		Lower Flexible Drive Shaft