

128700 to 128799

SERVICE ENGINE



SALES MANUAL

**MODEL 128700 SERIES ENGINES REPLACED WITH
 STANDARD SERVICE ENGINES**

In most cases, the Original Type numbers shown may be replaced by a Service Type Number without making any changes. Necessary changes of engine parts such as crankshafts, reduction parts, blower housings, etc., are noted. Other differences, such as mufflers, elbows, deflectors, etc., are not listed but are very important for safety and engine performance. Be sure the exhaust system on the replacement engine duplicates the system originally selected by the equipment manufacturer. Parts that are suitable for additional use should be transferred. Before making any conversion, check the data shown in the column labeled "REMOVE, ADD and NOTE." See if the changes, which are shown, are actually necessary on the application in question. Often a standard service engine will be a WORKABLE replacement without converting to such things as a special fuel tank or starter position.

If the crankshaft number does not appear in the "Original Engine" column, consult the Illustrated Parts List for the correct service replacement crankshaft number.

Engine Replacement Notes:

- NOTE 51:** Replacement engine listed is not available in the State of California. Repair with individual parts.
- NOTE 73:** Transfer Flywheel Assembly to the replacement engine.
- NOTE 88:** Transfer Muffler and/or Spark Arrester Assembly from the original engine if suitable for additional service or add new parts as required

Short Block Notes:

The SHORT BLOCK part number shown, is the assembly which can be used to rebuild the Original Type Number. If a letter appears after the short block number, it indicates the short block must be modified. The change denoted by each letter is as follows:

128700 to 128799

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0110	128702	493362	122K02	0515							All	3150	498826	
0120	128702	493363	122K02	0516					51		All	3100	498827	
0121	128702	493432	122K02	0515	1	690319	1	691851	73		All	3400	694809	
					1	691451	1	692978						
0505	128702		122K02	0518	1	690319	1	691291	73		All	3600	498828	
0621	128702	493432	122K02	0515	1	690319	1	691851	73		All	3400	694809	
					1	691451	1	692978						
0622	128702	493432	122K02	0515	1	690319	1	691851	73		All	3400	694809	
					1	691451	1	692978						
0624	128702	494984	122K02	0515							All	3100	498826	
0625	128702	493362	122K02	0515							All	3100	498826	
0626	128702		122K02	0515							All	3150	498826	
0627	128702	493362	122K02	0515	1	690319	1	691291	73		All	3500	498826	
0628	128702	493362	122K07	0560	1	690319	1	691291	73		All	3500	498826	
									88					
0629	128702	494984	122K02	0515							All	3100	498826	
0630	128702		122K02	0518	1	690319	1	691291	73		All	3600	498828	
0663	128702		122K02	0525					51		All	3000	498829	
0664	128702		12J802	2926					51		All	3000	498830	
0665	128702		122K02	0515							All	3000	498826	
0666	128702		122K02	0516					51		All	3000	498827	
0672	128702		122K02	0518	1	690319	1	691291	73		All	3500	498828	
1708	128702	691450	122K02	0525					51		All	3000	498829	
1709	128702	691452	122K02	0516					51		All	3000	498827	
1722	128702	692978	122K02	0515	1	690319	1	691851	73		All	3400	694809	
					1	691451	1	692978	88					
1772	128702		122K02	0518	1	690319	1	691291	73		All	3500	498828	
1773	128712	691482	128812	4305					51		All	3800	499527	

128700 to 128799

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
1774	128712	691482	128812	4305					51		All	3800	499527	
4705	128712		128812	4305					51		All	3800	499527	